




Replacing the K2 Shaft Encoder



Newer Style K2 Shaft encoder

Older Style K2 Shaft encoder

- 1. Remove the rubber cover from the edge of the Jog wheel.
- 2. Use $1/16^{\text{th}}$ Allen wrench to loosen the (2) setscrews on the wheel side.
- 3. Remove the wheel, then flip over the keyboard.
- 4. Remove the (6) screws to remove the back cover.
- 5. Remove the (9) screws holding the board in place.
- 6. Gently flip over and set the frame aside.
- 7. Remove the nut holding the shaft encoder and unplug.
- 8. Unsolder brown wire (note location to re-solder).
- 9. Install the new shaft encoder and solder brown wire.
- 10. Assemble in reverse order.